

## GUIDE FOR BUILDING AND CLASSING

# AUTOMATIC OR REMOTE CONTROL AND MONITORING FOR MACHINERY AND SYSTEMS (OTHER THAN PROPULSION) ON OFFSHORE INSTALLATIONS MARCH 2003

**CORRIGENDA/EDITORIALS – 1 October 2008**

**CORRIGENDA/EDITORIALS – 1 February 2014**

**CORRIGENDA/EDITORIALS – 1 March 2018**

**CORRIGENDA/EDITORIALS – 30 August 2018**

Page No.	Paragraph	Comments
<b>Section 1</b>	<b>General</b>	
1	1/1	Reference “ <i>ABS Guide for Building and Classing Facilities on Offshore Installations (Facilities Guide)</i> ” to read “ <i>ABS Rules for Building and Classing Facilities on Offshore Installations (Facilities Rules)</i> ”.
2	1/3.5	Reference “Chapter 9, Section 12 of the <i>Guide for Building and Classing Floating Production Installations</i> ” to read “7-2-4/17 of the <i>ABS Rules for Building and Classing Floating Production Installations (FPI Rules)</i> ”.
7	1/9.13.2	Reference “4-9-7/13.1 of the <i>Steel Vessel Rules</i> ” to read “4-9-8/13.1 of the <i>Steel Vessel Rules</i> ”.
7	1/9.13.3	Reference “Section 2, Table 1 below” to read “Section 1, Table 1 below”.
7	1/9.13.4	Reference “Appendix 1-1-A3/5 of the <i>Rules for Building and Classing Steel Vessels</i> ” to read “1-1-A3/5 of the <i>ABS Rules for Conditions of Classification – Offshore Units and Structures (Part 1)</i> ”. (2 places)
7	1/9.15.1	Reference “ <i>Facilities Guide</i> ” to read “ <i>Facilities Rules</i> ”.
7	1/9.15.2	Reference “ <i>Facilities Guide</i> ” to read “ <i>Facilities Rules</i> ”.

<b>Section 2</b>	<b>General</b>	
12	2/9	Re-number Paragraph 2/9.7 as 2/9.13.
17	2/Table 15	For Item A1, reference “5C-8-16/3.7” to read “5C-8-16/4.6”.
17	2/Table 15	For Items A2 and A3, reference “5C-8-16/3.6” to read “5C-8-16/4.5”.
17	2/Table 15	For Item E1, reference “5C-8-16/2.1” to read “5C-8-16/3.1”.
17	2/Table 15	For Item E2, reference “5C-8-16/3.1.2” to read “5C-8-16/4.6.2”.
17	2/Table 15	For Item E3, reference “5C-8-16/3.1.2, 5C-8-16/3.4” to read “5C-8-16/4.3.2, 5C-8-16/4.6.2”.
17	2/Table 15	For Item F1, reference “5C-8-16/2.2, 5C-8-16/3.1.2, 5C-8-16/3.4” to read “5C-8-16/3.2, 5C-8-16/4.6.2”.
17	2/Table 15	For Item G1, reference “5C-8-16/4.3” to read “5C-8-16/5.3”.
18	2/Table 16	For Items A1, A2, and A3, reference “5C-8-16/11.1” to read “5C-8-A7/3.5”.
18	2/Table 16	For Items D1 and D2, reference “5C-8-16/12.2” to read “5C-8-A7/3.7”.