

GUIDE FOR

LNG BUNKERING JANUARY 2017

CORRIGENDA/EDITORIALS – 1 March 2018

Page No.	Paragraph	Comments
Section 1 General		
4	1/7.5	Reference “ <i>ABS Guide for Propulsion Systems for LNG Carriers</i> ” to read “applicable sections of Part 5C, Chapter 8 of the <i>Steel Vessel Rules</i> ”.
Section 2 Vessel Arrangements and System Design		
6	2/5.1ii)	Reference “Section 4 of the <i>ABS Guide for Propulsion Systems for LNG Carriers</i> ” to read “Appendix 5C-8-A5 of the <i>Steel Vessel Rules</i> ”.
6	2/5.1ii)	Reference “4/2.1 and 4/3.3 of the <i>ABS Guide for Propulsion Systems for LNG Carriers</i> ” to read “5C-8-A5/3.1 and 5C-8-A5/5.5 of the <i>Steel Vessel Rules</i> ”.
6	2/5.1iii)	Reference “Section 5 of the <i>ABS Guide for Propulsion Systems for LNG Carriers</i> ” to read “Appendix 5C-8-A6 of the <i>Steel Vessel Rules</i> ”.
7	2/5.1iii)	Reference “Section 6 of the <i>ABS Guide for Propulsion Systems for LNG Carriers</i> ” to read “Appendix 5C-8-A7 of the <i>Steel Vessel Rules</i> ”.
7	2/5.1iv)	Reference “Section 4 of the <i>ABS Guide for Propulsion Systems for LNG Carriers</i> ” to read “Appendix 5C-8-A5 of the <i>Steel Vessel Rules</i> ”.
Appendix 1 List of Relevant Regulations/Standards/Guides		
19	A1/Table 1	Delete Item 3 “ <i>ABS Guide, ABS Guide for Propulsion Systems for LNG Carriers</i> ”.